






SENSOTORK® 701




DE Inbetriebnahme
EN Starting Up
ES Puesta en marcha
FR Démarrage
IT Avvio




service.stahlwille.de

STAHlwille Eduard Wille GmbH & Co. KG
Lindenallee 27 · 42349 Wuppertal · Deutschland
Tel.: +49 202 4791-0 · Fax: +49 202 4791-200
info@stahlwille.de · www.stahlwille.de

© STAHlwille Eduard Wille GmbH & Co. KG //
0-06-22 WEB // V 1.0 // 91979861




POWER ON




+ 1 x


MODE




UNIT



TARE



USER Configuration via SENSOMASTER 4



USER Configuration via SENSOTORK®

	XX,00 user Nm	USER DEFAULT
3 x [Power Button]	10,00 eval Nm	DEFAULT
SET 1 x [Power Button]	1,00 [+0,50] 20,00 eval Nm	
SAVE 3 x [Power Button]	[Down Arrow] [Up Arrow]	
START	0,00 eval Nm	
POWER OFF	10,00 user Nm	USER DEFAULT

POWER OFF

